


# MODBUS/TCP

## Fieldbus manual

Lexium Lexium MDrive Ethernet  
Products

V1.00,06.2013



MODBUS/TCP Fieldbus Manual for Lexium MDrive		
Date	Revision	Changes
06/27/2013	V1.00,06.2013	Initial Release

The information in Schneider Electric Motion USA product documentation and on this web site has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies.

Schneider Electric Motion USA reserves the right to make changes without further notice to any products to improve reliability, function or design. Schneider Electric Motion USA does not assume any liability arising out of the application or use of any product or circuit described; neither does it convey any license under its patent rights of others.

Schneider Electric Motion USA's general policy does not recommend the use of its products in life support or aircraft applications wherein a failure or malfunction of the product may directly threaten life or injury. Per the terms and conditions of sales of Schneider Electric Motion USA, the user of Schneider Electric Motion USA products in life support or aircraft applications assumes all risks of such use and indemnifies Schneider Electric Motion USA against all damages.

## Important information

This manual is part of the product.

Carefully read this manual and observe all instructions.

Keep this manual for future reference.

Hand this manual and all other pertinent product documentation over to all users of the product.

Carefully read and observe all safety instructions and the chapter "Before you begin - safety information".

This page intentionally left blank

**Table of Contents**

Important information ..... 3

**About this manual ..... 1**  
 Further reading..... 1

**1 Introduction..... 1-1**  
 1.1 About this manual..... 1-1  
 1.2 Supported protocols ..... 1-1  
 1.3 Documentation reference ..... 1-2  
 1.4 Product software ..... 1-2  
     1.4.1 Lexium MDrive Software Suite ..... 1-2

**2 Safety..... 2-1**  
 2.1 Qualification of personnel..... 2-1  
 2.2 Intended Use ..... 2-1  
 2.3 Hazard Categories ..... 2-2  
 2.4 Basic information ..... 2-3

**3 MODBUS Implementation ..... 3-1**  
 3.1 MODBUS overview ..... 3-1  
 3.2 Message format..... 3-2  
     3.2.1 ADU (application data unit)..... 3-3

**4 Function codes ..... 4-1**  
 4.1 Device ID..... 4-1  
     4.1.1 Read device identification – 43/ 14  
         (0x2B/0x0E)..... 4-1  
 4.2 Public function codes ..... 4-3  
     4.2.1 Read digital inputs 02 (0x02)..... 4-3  
     4.2.2 Read coils (digital outputs) – 01 (0x01) ..... 4-4  
     4.2.3 Write single coil (digital output) – 05 (0x05)..... 4-5  
     4.2.4 Read holding registers – 03 (0x03)..... 4-6  
     4.2.5 Write multiple registers – 16 (0x10) ..... 4-7  
 4.3 Manufacturer specific function codes ..... 4-8  
     4.3.1 Manufacturer specific commands using  
         65 (0x41) and 66 (0x42) ..... 4-8  
     4.3.2 Read manufacturer specific – 65 (0x41) ..... 4-12  
     4.3.3 Write manufacturer specific – 66 (0x42) ..... 4-13

**5 Register map..... 5-1**  
 5.1 hMTechnology specific registers ..... 5-5  
 5.2 User variable registers ..... 5-7

**6 TCP/IP Configuration Utility ..... 6-1**

## List of Figures

Figure 3.1: Example MODBUS network..... 3-1  
Figure 3.2: Client-server model..... 3-2  
Figure 3.3: Ethernet data packet for MODBUS/TCP..... 3-2  
Figure 3.4: MODBUS/TCP data packet construction ..... 3-3

## List of Tables

Table 3.1 MBAP header..... 3-3  
Table 4.1: Supported function codes ..... 4-1

---

## About this manual



---

The information provided in this manual supplements the product hardware manual.

*Source manuals* The latest versions of the manuals can be downloaded from the Internet at:

<http://motion.schneider-electric.com>

Applicable manuals for Lexium Lexium MDrive Ethernet products are:

- MCode Programming and Software Reference manual
- MODBUS/TCP Fieldbus manual
- EtherNet/IP Fieldbus manual

*Graphic User Interface software* For easier prototyping and development, a Graphic User Interface (GUI) is available for use with Lexium Lexium MDrive products. This software is available for download from the Internet at:

<http://motion.schneider-electric.com>

## Further reading

Recommended literature for further reading.

*Reference documents* The MODBUS Specification and Implementation guides  
<http://www.modbus.org/specs.php>

The MODBUS/TCP toolkit: <http://www.modbus.org/toolkit.php>

*User Association* MODBUS Organization: <http://www.modbus.org/>

Page intentionally left blank



---

# 1 Introduction

## 1.1 About this manual

This manual is for use with the Lexium Lexium MDrive Ethernet models when the Modbus/TCP protocol is needed. This manual was developed from the perspective that you already have an understanding of the MODBUS protocol.

For detailed technical information on the MODBUS/TCP specification, please see <http://www.modbus.org/>.

## 1.2 Supported protocols

The new Lexium Lexium MDrive Ethernet products support three protocols in a single package:

- 1) **EtherNet/IP** — EtherNet/IP protocol popularized by Allen Bradley and Rockwell Automation and managed by the ODVA.

If using the device using MCode/TCP, please see the EtherNet/IP Fieldbus Manual located on the web site at <http://www.motion.schneider-electric.com/downloads/manuals.html>.

- 2) **MCode/TCP** — Schneider Electric Motion USA's proprietary programming language for Lexium MDrive Ethernet products, adapted to utilize TCP/IP message formatting.

If using the device using MCode/TCP, please see the MCode Programming and Reference Manual located on the web site at <http://motion.schneider-electric.com>

- 3) **MODBUS/TCP** — A standard open industrial protocol supported by a variety of machine components such as programmable controllers, drives and controls, I/O modules and switches.

These protocols may be used separately or interchangeably, as is required by the constraints of the application by connecting to the port that the protocol is running on, 503 for MCode/TCP and 502 for MODBUS/TCP.

First configuration connection will need to be over MCode/TCP using the Ethernet Interface, which is part of the Lexium MDrive Software Suite to change the IP address of the device. The Suite and it's associated manual my be downloaded from the web site at:

<http://motion.schneider-electric.com>

The Information on MCode is found in the MCode Programming and Software Reference available on the web site at

<http://motion.schneider-electric.com>

---

## 1.3 Documentation reference

The following user's manuals are available for the MODBUS devices:

- Product hardware manual, describes the technical data and installation of the product.
- Product software manual, describes the configuration and programming of the product.
- Quick Reference, describes the basic wiring, connection and use of this product. The quick reference is shipped in printed form with the product.

This documentation is also available for download from our web site at: <http://www.motion.schneider-electric.com>.

## 1.4 Product software

### 1.4.1 Lexium MDrive Software Suite

The Ethernet Interface is a software tool for setting the IP, upgrading firmware and sending commands to the MODBUS device. It is part of the Lexium MDrive Software Suite.

This software is required for the initial setup of the device.

Installation and usages instructions are to be found in Lexium MDrive Software Suite Manual.

This software and manual may be downloaded from the web site at: <http://www.motion.schneider-electric.com>.

---

## 2 Safety

### 2.1 Qualification of personnel

Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation are authorized to work on and with this product. In addition, these persons must have received safety training to recognize and avoid hazards involved. These persons must have sufficient technical training, knowledge and experience and be able to foresee and detect potential hazards that may be caused by using the product, by changing the settings and by the mechanical, electrical and electronic equipment of the entire system in which the product is used.

All persons working on and with the product must be fully familiar with all applicable standards, directives, and accident prevention regulations when performing such work.

### 2.2 Intended Use

The functions described in this manual are only intended for use with the basic product; you must read and understand the appropriate product manual.

The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements and the technical data.

Prior to using the product, you must perform a risk assessment in view of the planned application. Based on the results, the appropriate safety measures must be implemented.

Since the product is used as a component in an entire system, you must ensure the safety of persons by means of the design of this entire system (for example, machine design).

Operate the product only with the specified cables and accessories. Use only genuine accessories and spare parts.

Any use other than the use explicitly permitted is prohibited and can result in hazards.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.

The product must NEVER be operated in explosive atmospheres (hazardous locations, Ex areas).and spare parts.

---

## 2.3 Hazard Categories

Safety instructions to the user are highlighted by safety alert symbols in the manual. In addition, labels with symbols and/or instructions are attached to the product that alert you to potential hazards.

Depending on the seriousness of the hazard, the safety instructions are divided into 4 hazard categories.

### ▲ DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.

### ▲ WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.

### ▲ CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

### CAUTION

CAUTION used without the safety alert symbol, is used to address practices not related to personal injury (e.g. **can result** in equipment damage).

2.4 Basic information

**▲ DANGER**

**UNINTENDED CONSEQUENCES OF EQUIPMENT OPERATION**

When the system is started, the drives are usually out of the operator’s view and cannot be visually monitored.

- Only start the system if there are no persons in the hazardous area.

**Failure to follow these instructions will result in death or serious injury.**

**▲ WARNING**

**LOSS OF CONTROL**

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop, overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical functions.
- System control paths may include communication links. Consideration must be given to the implication of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines. 1)
- Each implementation of the product must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death or serious injury.**

1) For USA: Additional information, refer to NEMA ICS 1.1 (latest edition), “Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control” and to NEMA ICS 7.1 (latest edition), “Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems”.

---

This page has been intentionally left blank.

### 3 MODBUS Implementation

#### 3.1 MODBUS overview

MODBUS is a communications interface developed in 1979 by PLC manufacturer Modicon, Inc. (now a brand of Schneider Electric). MODBUS is designed for multidrop networks based on a master-client architecture.

The availability of devices using MODBUS has made it a de facto standard for industrial communications network. MODBUS was originally developed for use with serial communications interfaces such as RS-232 and RS-485, MODBUS/TCP communications over TCP/IP has become a standard because of the ease of interface and simpler message format.




Figure 3.1: Example MODBUS network with Lexium MDrive products.

MODBUS/TCP is basically the MODBUS serial RTU encapsulated in a TCP/IP wrapper and is used for TCP/IP communications between client and server devices on an Ethernet TCP/IP network.




Figure 3.2: Client-server model

### 3.2 Message format

MODBUS/TCP uses the OSI (Open Systems Interconnection) networking model. The MODBUS ADU (Application Data Unit) makes up the OSI application layer and is wrapped inside the data array of the TCP/IP Ethernet data packet. Figure 3.3 below shows the construction of a TCP/IP Ethernet data packet used for the MODBUS/TCP protocol.




Figure 3.3: Construction of an ethernet data packet for MODBUS/TCP



### 3.2.1 ADU (application data unit)

A MODBUS/TCP data packet, or Application Data Unit (ADU) consists of two components:

- 1) MODBUS Application Protocol (MBAP) header
- 2) Protocol Data Unit (PDU)

The information contained in the ADU is embedded in the data portion of the TCP frame.




Figure 3.4: MODBUS/TCP data packet construction

*MBAP header*

The MBAP header is 7 bytes long and consists of the following fields made up of four fields”

Fields	Length	Description
Transaction identifier	2 bytes	ID of a MODBUS request/response transaction. This field is used for transaction pairing, the server will copy in the Transaction ID of the request into the response.
Protocol identifier	2 bytes	0 = MODBUS protocol
Length	2 bytes	Number of bytes following, including the Unit ID and the byte length of the PDU.
Unit identifier	1 byte	ID of a remote slave. Used for intra-system communications with other buses i.e. between MODBUS/TCP and a MODBUS serial line slave through a gateway.

Table 3.1 MBAP header

*Protocol Data Unit (PDU)* The PDU consists of 2 parts:

- 1) **Function code:** the function code identifies the action to be taken using the data bytes that will follow. These functions are covered in detail in Section 4 of this document. Basic functions are:  
Reading inputs, writing coils (digital outputs), read/write registers and manufacturer specific configuration functions.
- 2) **Data:** The data contained in the PDU, it will consist of the data and/or parameters associated with the commands to operate your Lexium MDrive product.

## 4 Function codes

The Lexium MDrive supports the following function codes:

Function code		
dec	hex	Description
<b>Device ID</b>		
43/14	0x2B/0x0E	Read device identification
<b>Public</b>		
02	0x02	Read digital inputs
01	0x01	Read coils (digital outputs)
05	0x05	Write single coil (digital output)
03	0x03	Read holding register
16	0x10	Write multiple registers
<b>Manufacturer specific</b>		
65	0x41	Read specific functions
66	0x42	Write specific functions

Table 4.1: Supported function codes

*Exception codes*

Each function has 4 error, or exception codes that will return in case of an error with the transaction. They are:

- 01 – Illegal or not supported function
- 02 – Illegal data address
- 03 – Illegal data value
- 04 – Slave device failure

### 4.1 Device ID

#### 4.1.1 Read device identification – 43/14 (0x2B/0x0E)

The device type contains information about your Lexium MDrive product, importantly the part number, serial number, and firmware version installed.

*Request*

	Length	Value
Function code	1 byte	0x2B
MEI* type	1 byte	0x0E
Read device ID code	1 byte	01 / 02 / 03 / 04
Object ID	1 byte	0x00 – 0x06

\*MODBUS Encapsulated Interface

*Response*

	<b>Length</b>	<b>Value</b>
Function code	1 byte	0x2B
MEI type	1 byte	0x0E
Read device ID code	1 byte	
Conformity level	1 byte	
More follows	1 byte	
NextObjectId	1 byte	0x00
Number Of Objects	1 byte	0x06
Object Id	1 byte	0x00
Object Length	1 byte	0x03
Object Value	3 bytes	"SEM USA"
Object Id	1 byte	0x01
Object Length	1 byte	0xXX
Object Value	X bytes	"LMDxExxx"
Object Id	1 byte	0x02
Object Length	1 byte	0x08
Object Value	8 bytes	"4.0.0.0"
Object Id	1 byte	0x03
Object Length	1 byte	0x20
Object Value	32 bytes	"www.motion.schneider-electric.com"
Object Id	1 byte	0x04
Object Length	1 byte	0x0A
Object Value	10 bytes	Lexium MDrive Ethernet
Object Id	1 byte	0x05
Object Length	1 byte	0xXX
Object Value	X bytes	"Serial number"
Object Id	1 byte	0x06
Object Length	1 byte	0x0C
Object Value	12 bytes	LMDCM X.XXX, Hw: X.X

## 4.2 Public function codes

### 4.2.1 Read digital inputs 02 (0x02)

Function 02 is used to read the state of the digital inputs 1 - 4 on your Lexium MDrive product. The request PDU contains the starting address of the first input specified, and the number of inputs.

In the response message the input states are packaged as 1 input per bit of the data field where status is indicated as 1 = ON and 0 = OFF. The LSB of the data byte will be the address of the input in the request.

NOTE: Digital inputs on the Lexium MDrive may also be read using the holding registers.

NOTE 2: The inputs must be configured as such using the manufacturer specific function code 66 (0x42).

*Request*

	Length	Value
Function code	1 byte	0x02
Starting Address	2 bytes	0x0000 – 0x0003
Quantity of inputs	1 byte	1 to 4

*Response*

	Length	Value
Function code	1 byte	0x02
Byte Count	1 byte	1 to 4
Input status	1 to 4 bytes	

*Error*

	Length	Value
Error code	1 byte	0x82
Exception	1 byte	01, 02, 03 or 04
Input status	1 to 4 bytes	

*Example*

Example shows a read of all 4 Lexium MDrive digital inputs, the response shows input states: I1=1, I2=1, I3=0, I4=1. Input 1 is the input address and is therefore the LSB,

Request		Response	
Function	0x02	Function	0x02
Starting address Hi	0x00	Byte count	0x01
Starting address Lo	0x2D	Input status 4 – 1	0x0F
Qty of inputs Hi	0x00		
Qty of inputs Lo	0x04		

### 4.2.2 Read coils (digital outputs) – 01 (0x01)

Function 01 is used to read the state of the digital outputs 1 - 4 on your Lexium MDrive product. The request PDU contains the starting address of the first output specified, and the number of outputs.

In the response message the output states are packaged as 1 output per bit of the data field where status is indicated as 1 = ON and 0 = OFF. The LSB of the data byte will be the output of the address in the request.

NOTE: Digital outputs on the Lexium MDrive may also be read using the holding registers.

NOTE 2: The outputs must be configured as such using the manufacturer specific function code 66 (0x42).

#### *Request*

	Length	Value
Function code	1 byte	0x01
Starting Address	2 bytes	0x0000
Quantity of outputs	1 byte	1 to 4

#### *Response*

	Length	Value
Function code	1 byte	0x01
Byte Count	1 byte	1 to 4
Input status	1 to 4 bytes	

#### *Error*

	Length	Value
Error code	1 byte	0x81
Exception	1 byte	01, 02, 03 or 04
Input status	1 to 4 bytes	

#### *Example*

Example shows a read of all 4 Lexium MDrive digital outputs, the response shows outputs states: O1=1, O2=0, O3=1, O4=0. Output 1 is the output address and is therefore the LSB,

Request		Response	
Function	0x01	Function	0x02
Starting address Hi	0x00	Byte count	0x01
Starting address Lo	0x00	Output status 4 – 1	0x00
Qty of outputs Hi	0x00		
Qty of outputs Lo	0x04		

### 4.2.3 Write single coil (digital output) – 05 (0x05)

This function is used to turn a single output point ON or OFF.

The state is specified by a constant in the request data field:

- 0xFF00 – turns the output ON
- 0x0000 – turns the output OFF

All other values are illegal and will return an exception code 03: Illegal data value.

NOTE: Digital outputs on the Lexium MDrive may also be written using the holding registers.

NOTE 2: The outputs must be configured as such using the manufacturer specific function code 66 (0x42).

*Request*

	Length	Value
Function code	1 byte	0x05
Output address	2 bytes	0x0000 – 0x0003
Output value	2 bytes	0x0000 or 0xFF00

*Response*

	Length	Value
Function code	1 byte	0x05
Output address	2 bytes	0x0000 – 0x0003
Output value	2 bytes	0x0000 or 0xFF00

*Error*

	Length	Value
Error code	1 byte	0x85
Exception	1 byte	01, 02, 03 or 04

*Example*

Example shows setting output 3 to an ON state.

Request		Response	
Function	0x05	Function	0x05
Output address Hi	0x00	Output address Hi	0x00
Output address Lo	0x00	Output address Lo	0x00
Output value Hi	0xFF	Output value Hi	0xFF
Output value Lo	0x00	Output value Lo	0x00

#### 4.2.4 Read holding registers – 03 (0x03)

This function code is used to read a contiguous block of holding registers in your Lexium MDrive. The request PDU specifies the starting register address and the number of registers.

Lexium MDrive command data mapped to the holding registers measure 1, 2 or 4 bytes in length, therefore you will not need to read more than two consecutive registers per request.

NOTE: A number of registers are marked as reserved. Use of any of these registers will return an exception code 02: illegal data address.

See Section 5 of this document for the register map.

##### *Request*

	Length	Value
Function code	1 byte	0x03
Starting address	2 bytes	0x0000 – 0x00B7*
Each address	2 bytes	1 to 2

\*A number of addresses in this block are reserved for future use and will return an error.

##### *Response*

	Length	Value
Function code	1 byte	0x03
Byte count	2 bytes	1 – 4
Register value	2 bytes	0x00 to 0x04

##### *Error*

	Length	Value
Error code	1 byte	0x83
Exception	1 byte	01, 02, 03 or 04

##### *Example*

Example shows reading registers 0x008A and 0x008B (maximum velocity). The value reads as 0x00 0B B8 00 or decimal 768000 steps/second.

Request		Response	
Function	0x03	Function	0x0F
Starting address Hi	0x00	Byte count	0x04
Starting address Lo	0x8B	Register value Hi	0xB8
Qty of registers Hi	0x00	Register value Lo	0x00
Qty of registers Lo	0x02	Register value Hi	0xB8
		Register value Lo	0x0B



### 4.2.5 Write multiple registers – 16 (0x10)

This function code is used to write a contiguous block of registers in your Lexium MDrive. The request PDU specifies the starting register address and the number of registers to be written.

Lexium MDrive command data mapped to the registers measure 1, 2 or 4 bytes in length, therefore you will not need to write more than two consecutive registers per request.

NOTE: A number of registers are marked as reserved. Use of any of these registers will return an exception code 02: illegal data address.

See Section 5 of this document for the register map.

*Request*

	Length	Value
Function code	1 byte	0x10
Starting address	2 bytes	0x0000 – 0x00B7*
Each address	2 bytes	1 to 2
Qty of addresses	1 byte	2 or 4
Registers value	to 4 bytes	value

\*A number of addresses in this block are reserved for future use and will return an error.

*Response*

	Length	Value
Function code	1 byte	0x10
Starting address	2 bytes	0x0000 – 0x00B7*
Qty of registers	2 bytes	0x0001 to 0x0002

*Error*

	Length	Value
Error code	1 byte	0x90
Exception	1 byte	01, 02, 03 or 04

*Example*

Example shows writing registers 0x008A and 0x008B (maximum velocity). The value will be set as decimal 600000 steps/second, or 0x00 09 27 C0.

Request		Response	
Function	0x10	Function	0x10
Starting address Hi	0x00	Starting address Hi	0x00
Starting address Lo	0x8A	Starting address Lo	0x8A
Qty of registers Hi	0x00	Qty of registers Hi	0x00
Qty of registers Lo	0x8B	Qty of registers Lo	0x8B
Byte count	0x04		
Registers value Hi	0x27		
Registers value Lo	0xC0		
Registers value Hi	0x00		
Registers value Lo	0x09		

### 4.3 Manufacturer specific function codes

The device supports two manufacturer specific function codes:

- 65 (0x41) – Read specific functions
- 66 (0x42) – Write specific functions

*Manufacturer functions*

Function	R/W	Function	R/W
Setup input points 1 – 4	R/W	End program (E)	WO
Setup output points 1 – 3	R/W	Execute program (EX)	WO
Setup Analog input	R/W	Pause program (RS)	WO
Trip on Relative Position (TR)	R/W	Resume program (RS)	WO
Make Up mode (MU)	R/W		

#### 4.3.1 Manufacturer specific commands using 65 (0x41) and 66 (0x42)

*Input setup*

The ASCII of the command mnemonic is sent in reverse order in the request PDU i.e. SI, SO etc. The parameter string is written or read in normal sequence.

Function	<b>65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc</b>						
MCode mnemonic	<b>Is (Input setup)</b>						
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x53 0x49					
Parameter data length	6 – 7 bytes						
Parameter string example	Params	<b>A</b>	<b>B</b>				<b>C</b>
	ASCII	= 0	,	0	,	0	
	Hex	3D 30 2C	30 2C				30

**Parameters**

A - Line number		B- I/O type			C – Active Hi/Lo		
Input		Input functions					
dec	hex	dec	hex	function	dec	hex	
1	31	0	30	General purpose	0	30	Active Lo
2	32	1	31	Homing	1	31	Active Hi
3	33	2	32	Limit +			
4	34	3	33	Limit –			
		5	35	Soft stop			
		7	37	Jog +			
		8	38	Jog –			
		11	31 31	Reset			
		12	31 32	Capture input			

*Output setup*

The ASCII of the command mnemonic is sent in revers order in the request PDU i.e. SO etc. The parameter string is written or read in normal sequence.

Function	<b>65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc</b>					
MCode mnemonic	<b>Os(Output setup)</b>					
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x53 0x4F				
Parameter data length	6 – 7 bytes					
Parameter string example	Params	<b>A</b>	<b>B</b>	<b>C</b>		
	ASCII	= 0	,	0	,	0
	Hex	3D 30 2C	30 2C	30		

**Parameters**

A - Line number		B- I/O type			C – Active Hi/Lo		
Output		Output Functions					
1	31	16	31 36	General purpose	dec	hex	
2	32	17	31 37	Moving	0	30	Active Lo
3	33	18	31 38	Fault	1	31	Active Hi
		20	32 30	Velocity changing			
		21	32 31	Locked rotor			
		23	32 33	Moving to position			
		24	32 34	hMTechnology circuitry active			
		25	32 35	Make-up active			
		26	32 36	Encoder channel A			
		27	32 37	Encoder channel B			
		28	32 38	Trip (Output 3 only)			
		29	32 39	Attention			

*Analog input setup*

The ASCII of the command mnemonic is sent in revers order in the request PDU i.e. SI. The parameter string is written or read in normal sequence.

The analog input may be configured for voltage or current mode with ranges of 0 to 5 VDC, 0 to 10 VDC, 0 to 20 mA or 4 to 20 mA.

Function	<b>65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc</b>					
MCode mnemonic	<b>Is (Analog Input)</b>					
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x53 0x49				
Parameter data length	4 – 5 bytes					
Parameter string example	Params	<b>A</b>	<b>B</b>	<b>C</b>		
	ASCII	= 5	,	9	,	0
	Hex	3D 35 2C	39 2C	30		

See parameters table below for details

**Parameters**

A – Input mode			B – Input range		
dec	hex	mode	dec	hex	range
9	39	Voltage	0	30	0 – 5 VDC
			1	31	0 – 10 VDC
10	31 30	Current	0	30	0 – 20 mA
			1	31	4 – 20 mA

*Trip on relative position*

The ASCII of the command mnemonic is sent in reverse order in the request PDU i.e. RT. The parameter string is written or read in normal sequence.

Note that the only trip function available is trip on relative position. To re-enable the trip, use register 0x007D.

Function	<b>65 (0x41) Read Mfg Spc, 66 (0x42) Write Mfg Spc</b>						
MCode mnemonic	<b>TR (Trip on relative position)</b>						
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x52 0x54					
Parameter data length	Up to 11 bytes						
	ASCII	=	6	5	0	0	0
	Hex	3D	36	35	30	30	30

*End*

Stops the execution of a program.

Function	<b>65 (0x41) Read Mfg Spc</b>					
MCode mnemonic	<b>E (Stop program execution)</b>					
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x20 0x45				
Parameter data length	0 bytes					

*Execute program*

Executes the address or label of a stored MCode/TCP program.



**NOTE: The program resident CANNOT have any print statements in the code.**

User variables that need to be read over MODBUS/TCP during program execution must be read using Registers R1 – R4 and V1 – V8 using the associated register (See Section 5: Register Map). If using V1 – V8, they must be declared within the program using the VA (Create user variable) MCode command.

The example below shows the programmed labeled A3 being executed.

Function	<b>66 (0x42) Write Mfg Spc</b>						
MCode mnemonic	<b>EX (Execute program)</b>						
Mnemonic	Hi word	0x20 0x20					
	Lo word	0x58 0x454					
Parameter data length	Up to 4 bytes						
	ASCII	A	3				
	Hex	41	33				

*Pause program*

Pauses a running MCode/TCP program.

Function	<b>66 (0x42) Write Mfg Spc</b>					
MCode mnemonic	<b>PS (Pause program)</b>					
Mnemonic	Hi word	0x20 0x20				
	Lo word	0x53 0x50				
Parameter data length	0 bytes					

*Resume program* Resumes a paused MCode/TCP program.

Function	<b>66 (0x42) Write Mfg Spc</b>	
MCode mnemonic	<b>RS (Resume program)</b>	
Mnemonic	Hi word	0x20 0x20
	Lo word	0x53 0x52
Parameter data length	0 bytes	

*Make up mode (hMTechnology only)* Sets the mode for hMTechnology make up steps

Function	<b>66 (0x42) Write Mfg Spc</b>	
MCode mnemonic	<b>MU (Make up mode)</b>	
Mnemonic	Hi word	0x20 0x20
	Lo word	0x55 0x4D
Parameter data length	4 bytes	
Parameter string example	Params	<b>A</b> <b>B</b>
	ASCII	= 2 , 0
	Hex	3D 32 2C 30

See parameters table below for details

**Parameters**

A – Make up mode			B – Parameter		
dec	hex	mode	dec	hex	range
0	30	Off	0	30	Use lead/lag
1	31	Use make up frequency	1	31	Clear lead/lag
2	32	Use system speed			

### 4.3.2 Read manufacturer specific – 65 (0x41)

#### *Request*

	Length	Value
Function code	1 byte	0x41
Mnemonic Hi word	2 bytes	0x2020 0x2020/2033*
Mnemonic Lo word	2 bytes	See section 4.3.1 for listing

\*For capture/trip I/O point.

#### *Response*

	Length	Value
Function code	1 byte	0x41
Byte count	2 bytes	N* (quantity of characters returned)
Response	n bytes	n=N or N+1

#### *Error*

	Length	Value
Error code	1 byte	0xC1
Exception	1 byte	01, 02, 03 or 04

*Example* Example shows reading the setting of the trip on relative input (TR).

Request		Response	
Function	0x41	Function	0x41
Mnemonic Hi word	0x20	Byte count	0x07
	0x20		0x30
Mnemonic Lo word	0x52	Response	0x2C
	0x54		0x20
			0x30
			0x2C
			0x20
			0x30

**4.3.3 Write manufacturer specific – 66 (0x42)**

*Request*

	Length	Value
Function code	1 byte	0x42
Mnemonic Hi word	2 bytes	0x2020 0x2020/2033*
Mnemonic Lo word	2 bytes	See section 4.3.1 for listing
Byte count	1 byte	1-n bytes (28 max)
Parameter data string	n bytes	See section 4.3.1 for listing

\*For capture/trip I/O point.

*Response*

	Length	Value
Function code	1 byte	0x42
Byte count written	1 bytes	N* (quantity of characters returned)
Mnemonic Hi word	2 bytes	0x2020 0x2020/2033*
Mnemonic Lo word	2 bytes	See section 4.3.1 for listing

*Error*

	Length	Value
Error code	1 byte	0xC2
Exception	1 byte	01, 02, 03 or 04

*Example*

Example shows setting input 1 (S1). The input is shown set to a general purpose sinking input which is active when Hi, or S1=0,1,0. Note that the data string includes all of the characters, including the equal sign and the commas.

Request		Response	
Function	0x41	Function	0x41
Mnemonic Hi word	0x20	Bytes written	0x04
	0x20	Mnemonic Hi word	0x20
Mnemonic Lo word	0x31		0x20
	0x53	Mnemonic Lo word	0x31
Byte count	0x06		0x53
Parameter data string	0x3D		
	0x30		
	0x2C		
	0x31		
	0x2C		
	0x30		

---

Page intentionally left blank



## 5 Register map

Function	Address	Bytes	Description	Range	Default	MCode
<b>Acceleration</b>	0x0000 - 0x0001	4	Sets the acceleration rate in steps per second <sup>2</sup> .	91 to 1525878997	1000000	A
<b>Reserved</b>	0x0002-3	—	Reserved	—	—	—
<b>Busy</b>	0x0004	1	MCode program executing	—	—	BY
<b>Counter 1</b>	0x0005 - 0x0006	4	Variable contains the count of clock pulses generated by the device.	-2147483648 to +2147483647	0	C1
<b>Counter 2</b>	0x0007 - 0x0008	4	Variable contains the count of encoder counts read by the device. (Closed loop only)	-2147483648 to +2147483647	0	C2
<b>Software reset enable</b>	0x0009	1	Flag configures the device to respond (1) or not respond (0) to a CTRL+C software reset.	0/1	1	CE
<b>Reserved</b>	0x000A-E	—	Reserved	—	—	—
<b>Input 1 debounce</b>	0x000F	1	Sets digital filtering in milliseconds. Input must be stable for the set time before state change is detected.	0 – 255	0	D1
<b>Input 2 debounce</b>	0x0010	D2				
<b>Input 3 debounce</b>	0x0011	D3				
<b>Input 4 debounce</b>	0x0012	D4				
<b>Analog input filter</b>	0x0013	1	Filter does continuous average by computing: $((X-1)/X)*\text{current reading} + (1 / X)$ If X = 10, then: $((\text{current averaged value} * 9)/10) + (\text{new reading} / 10) = \text{NEW current averaged value}$ .	0 – 255	0	D5
<b>Reserved</b>	0x0014-17	—	Reserved	—	—	—
<b>Deceleration</b>	0x0018 - 0x0019	4	Sets deceleration rate in steps per second <sup>2</sup> .	91 – 1525878997	1000000	D
<b>Deadband <sup>1</sup></b>	0x001A	2	Encoder deadband (Closed loop only)	0 to ±65000	10	DB
<b>Decrement variable</b>	0x001B	1	instruction will decrement the specified variable by one.	—	—	DC
<b>Drive enable</b>	0x001C	1	Flag enables (1) or disables (0) the drive portion of the device.	0/1	1	DE
<b>Reserved</b>	0x001D	—	Reserved	—	—	—
<b>Encode enable</b>	0x001E	1	Enable encoder functions (Closed loop only)	0/1	0	EE
<b>Error flag</b>	0x001F	1	Flag indicates whether an error condition exists (1) or not (0).	0/1	0	EF
<b>Reserved</b>	0x0020	—	Reserved	—	—	—
<b>Error</b>	0x0021	2	Variable holds the error code of the last error. must be read or set to 0 to clear.	—	0	ER
<b>Reserved</b>	0x0022	—	Reserved	—	—	—
<b>Filter capture</b>	0x0024	1	Sets the digital filtering to be applied to Input 1 when configured as a Capture input	0 to 9	0	FC
<b>Reserved</b>	0x0025	—	Reserved	—	—	—
<b>Filter Motion</b>	0x0026	1	Digital filtering	0 to 9	0	FM
<b>Reserved</b>	0x0027-28	—	Reserved	—	—	—
<b>Holding current</b>	0x0029	1	Sets the motor holding current in percent (%)	0 to 100	5	HC
<b>Home to Index</b>	0x002A	1	Home to i encoder index mark mode	1 to 4	—	HI

Function	Address	Bytes	Description	Range	Default	MCode
<b>Homing mode</b>	0x002B	1	Sets the behavior of the axis for homing routines: Mode=1 - Slew – at VM, creep + at VI Mode=2 - Slew – at VM, creep – at VI Mode=3 - Slew + at VM, creep – at VI. Mode=4 - Slew + at VM, creep + at VI	1 – 4		HM
<b>Hold current delay time</b>	0x002C	2	Set the time in milliseconds between the cessation of motion and shift to holding current percent. Total time is represented by the sum of 0x002C+0x0049 (motor settling delay time. The sum cannot be more than 65535 msec.	0 (no delay) or 2 – 65535	500	HT
<b>Read input 1</b>	0x002D	1	Read the logic state of the specified input.	0/1	—	I1
<b>Read input 2</b>	0x002E					I2
<b>Read input 3</b>	0x002F					I3
<b>Read input 4</b>	0x0030					I4
<b>Read analog input</b>	0x0031		Read the value of the analog input in counts.	0 – 1023	—	I5
<b>Read index mark <sup>1</sup></b>	0.0032	1	This variable will read the on/off state of the Encoder Index Mark (Closed loop only)	0/1	—	I6
<b>Reserved</b>	0x0033-36	—	Reserved	—	—	—
<b>Increment variable</b>	0x0037	1	Increments the specified variable by one.	—	—	IC
<b>Reserved</b>	0x0038-3A	—	Reserved	—	—	—
<b>Read all inputs as BCD</b>	0x003B	1	Reads the logic states of inputs 1-4 and returns them as a decimal value. Input 1 will represent the LSb..	0 – 15	—	IN
<b>Initialize parameters</b>	0x003C	1	Reset all parameters to initial values	—	—	IP
<b>Internal temperature</b>	0x003D	1	Read the internal temperature of the device	—	—	IT
<b>Reserved</b>	0x003E	—	Reserved	—	—	—
<b>Jog enable</b>	0x003F	1	Enables (1)/disables(0) jog functions when inputs are configured as Jog+ and Jog –.	0/1	0	JE
<b>Reserved</b>	0x0040-41	—	Reserved	—	—	—
<b>Limit stop mode</b>	0x0042	1	Sets the behavior of the axis upon reaching a limit switch. Mode=1 – Normal limit function with decel ramp. Mode=2 – Stops motion with decel ramp, no homing. Mode=3 – Stops motion with decel ramp, stops program. Mode=4 – Normal limit function, no decel. Mode=5 – Stops motion, no decel, no homing. Mode=6 – Stops motion, stops program, no decel.	1 – 6	1	LM
<b>Move to absolute position</b>	0x0043 - 0x0044	4	Point-to-point move to a ± absolute position.	—	—	MA
<b>Moving to position</b>	0x0045	1	Indicates that the axis is moving (1) to an absolute or relative position or stopped (0).	0/1	0	MP
<b>Move to relative position</b>	0x0046 - 0x0047	4	Point-to-point move to a ± position relative distance from current position.	—	—	MR

Function	Address	Bytes	Description	Range	Default	MCode																																																							
<b>Microstep resolution</b>	0x0048	1	Set the microstep resolution in microsteps per motor full step.	See table	256	MS																																																							
			<table border="1"> <thead> <tr> <th colspan="11">Available Microsteps Per Revolution</th> </tr> <tr> <th>0x0048=</th> <th>1</th> <th>2</th> <th>4</th> <th>5</th> <th>8</th> <th>10</th> <th>16</th> <th>25</th> <th>32</th> <th>50</th> </tr> </thead> <tbody> <tr> <td>steps/rev</td> <td>200</td> <td>400</td> <td>800</td> <td>1000</td> <td>1600</td> <td>2000</td> <td>3200</td> <td>5000</td> <td>6400</td> <td>10000</td> </tr> <tr> <th>0x0048=</th> <th>64</th> <th>100</th> <th>125</th> <th>128</th> <th>200</th> <th>250</th> <th>256</th> <th>180</th> <th>108</th> <th>127</th> </tr> <tr> <td>steps/rev</td> <td>12800</td> <td>20000</td> <td>25000</td> <td>25600</td> <td>40000</td> <td>50000</td> <td>51200</td> <td>36000<sup>1</sup></td> <td>21600<sup>2</sup></td> <td>25400<sup>3</sup></td> </tr> </tbody> </table> <p>1=0.01 deg/μstep    2=1 arc minute/μstep    3=0.001 mm/μstep</p>				Available Microsteps Per Revolution											0x0048=	1	2	4	5	8	10	16	25	32	50	steps/rev	200	400	800	1000	1600	2000	3200	5000	6400	10000	0x0048=	64	100	125	128	200	250	256	180	108	127	steps/rev	12800	20000	25000	25600	40000	50000	51200	36000 <sup>1</sup>	21600 <sup>2</sup>	25400 <sup>3</sup>
Available Microsteps Per Revolution																																																													
0x0048=	1	2	4	5	8	10	16	25	32	50																																																			
steps/rev	200	400	800	1000	1600	2000	3200	5000	6400	10000																																																			
0x0048=	64	100	125	128	200	250	256	180	108	127																																																			
steps/rev	12800	20000	25000	25600	40000	50000	51200	36000 <sup>1</sup>	21600 <sup>2</sup>	25400 <sup>3</sup>																																																			
<b>Motor settling delay time</b>	0x0049	2	Specifies the motor settling delay time in milliseconds. This allows the motor to settle following a move. This variable is added to 0x002C to determine the total time before shifting to holding current. The sum cannot be more than 65535 msec.	0 – 65000	0	MT																																																							
<b>Moving</b>	0x004A	1	Indicates whether the axis is in motion (1) or stationary (0).	0/1	0	MV																																																							
<b>Write output 1</b>	0x004B	1	Write (set) the logic state of the specified output.	0/1	—	O1																																																							
<b>Write output 2</b>	0x004C	O2																																																											
<b>Write output 3</b>	0x004D	O3																																																											
<b>Output fault</b>	0x004E	1	Output fault flag indicates a faulted state of an output when true.	0/1	0	OF																																																							
<b>Reserved</b>	0x004F-55	—	Reserved	—	—	—																																																							
<b>Set outputs 1 - 4 as a group</b>	0x0056	1	Set outputs 1-4 as one 4 bit binary value. The value is entered in decimal, with a range of 0-15 in binary where output 1 will be the LSb	0 – 15	—	OT																																																							
<b>Position counter</b>	0x0057 - 0x0058	4	Sets or reads the axis ± position in motor steps. The value of the register will be used as the reference point for absolute and relative moves.	-2147483648 – +2147483647	0	P																																																							
<b>Position capture at trip</b>	0x0059 - 0x005A	4	Captures axis position during a trip event. Activation will occur upon any trip function EXCEPT a position trip.	—	—	PC																																																							
<b>Reserved</b>	0x005B	—	Reserved	—	—	—																																																							
<b>Position maintenance</b>	0x005C	1	Enables (1) or disables (0) position maintenance functions (Closed loop only)	0/1	0	PM																																																							
<b>Reserved</b>	0x005D-5E	—	Reserved	—	—	—																																																							
<b>User register 1</b>	0x005F - 0x0060	4	registers may contain up to 11 digits including the sign and may be used to store and retrieve data.	32 bit	—	R1																																																							
<b>User register 2</b>	0x0061 - 0x0062					R2																																																							
<b>User register 3</b>	0x0063 - 0x0064					R3																																																							
<b>User register 4</b>	0x0065 - 0x0066					R4																																																							
<b>Run current</b>	0x0067	1	Sets the motor run current in percent (%).	1 to 100	25	RC																																																							
<b>Reserved</b>	0x0068-75	—	Reserved	—	—	—																																																							

Function	Address	Bytes	Description	Range	Default	MCode
<b>Save</b>	0x0076	1	Saves variables and flags in working memory to NVM.		—	S
<b>Stall factor</b>	0x0077	2	Difference between commanded position and encoder counts at which a stall is indicated (Closed loop only).	0 to 65000	15	SF
<b>Slew axis</b>	0x0078 - 0x0079	4	Slews the axis at velocity in steps/second in the specified $\pm$ direction, Slew velocity is independent of 0x008B (maximum velocity).	$\pm 5000000$	—	SL
<b>Stall mode</b>	0x007A	1	Stall detection mode determines the response to a stall detect, either motion stops (0) or attempts to continue (1) (Closed loop only).	0/1	0	SM
<b>Stall flag</b>	0x007B	1	indicates a motor stall (1) or not stalled (0) (Closed loop only).	0/1	0	ST
<b>Reserved</b>	0x007C	—	Reserved	—	—	—
<b>Trip enable</b>	0x007D	1	Enables/re-enables trip functions as specified by the table below. Multiple trips may be specified by adding the trip definitions i.e. 0x007D=10 will allow trip on position (2) and trip on time (8).  Trips are set up using manufacturer function codes 65 (0x41) and 66 (0x42)  <b>Trip enable definitions:</b> 0 – Trip functions disabled. 1 – Reserved 2 – Reserved 4 – Reserved 8 – Reserved 16 – Trip on relative position 32 – Reserved	0 – 43	0	TE
<b>Reserved</b>	0x007E-84	—	Reserved	—	—	—
<b>Read axis velocity</b>	0x0085 - 0x0086	4	Reads the current velocity in motor steps per second.  NOTE: If hMTechnology circuitry is in make-up mode, 0x0085-86 will not return an accurate value. When the hMTechnology product is in torque control mode 0x0085-86 will return a zero (0). Read only variable.	—	—	V
<b>Reserved</b>	0x0087	—	Reserved	—	—	—
<b>Velocity is changing</b>	0x0088	1	Axis velocity is changing (1) or constant (0). Read only status flag.	0/1	0	VC
<b>Set initial velocity</b>	0x0089 - 0x008A	4	Set the initial velocity of the axis in motor steps per second.	1 to max. velocity – 1	1000	VI
<b>Set maximum velocity</b>	0x008B - 0x008C	4	Set the maximum velocity of the axis in motor steps per second.	Initial velocity +1 to 5000000	768000	VM
<b>Warning temp</b>	0x008D	—	Sets the temperature at which a warning error is asserted/	0 to 84	80	WT

## 5.1 hMTechnology specific registers

Function	Address	Bytes	Description	Range	Default	MCode
<b>Set hMTechnology mode</b>	0x008E	1	Sets the hMTechnology operational behavior to one of four modes, detailed below:	0 – 3	2	AS
			0 hMTechnology circuitry disabled.			
			1 Fixed current mode. Current is set by the run and hold current commands, Speed is set by the system speed command.			
			2 Variable current mode. Current will vary as needed to position the load with the maximum current set by the run current command.			
			3 Torque mode, torque and speed will vary as needed to move/ position the load with the maximum torque % and speed as specified by the torque and torque-speed commands.			
<b>Read hMTechnology status</b>	0x008F	1	Read only status flag will return the conditions listed below. If multiple conditions exist the result is additive. i.e. At zero (64) and Calibration complete (128) AF=192	1 – 255	—	AF
			1 – Rotor lead limit reached.			
			2 – Rotor lag limit reached.			
			4 – Maximum lead/lag limit reached.			
			8 – Locked rotor.			
			16 – hMTechnology mode is active.			
			32 – Hardware fault condition exists.			
			64 – At zero (0).			
			128 – Calibration s complete.			
<b>Reserved</b>	0x0090	—	—	—	—	—

Function	Address	Bytes	Description	Range	Default	MCode
<b>Set control bounds</b>	0x0091	1	The control bounds are limits which configure the hMTechnology circuitry for best speed or torque performance. For torque mode operation the control bounds are preset for best torque performance.  0 – 1.1 full steps (best torque performance). 1 – 1.3 full steps (best overall performance). 2 – 1.5 full steps (best overall performance). 3 – 1.7 full steps (best speed performance).	0 – 3	1	CB
<b>Reserved</b>	0x0092	—	—	—	—	—
<b>Clear locked rotor</b>	0x0093	1	Will clear a locked rotor fault, re-enable the output bridge and initiate a timed calibration.	—	—	CF
<b>Reserved</b>	0x0094	—	—	—	—	—
<b>Lead limits</b>	0x0095 – 0x0096	4	Sets the rotor lead limit in motor steps	0 – 2147483647	102400	LD
<b>Lag limits</b>	0x0097 – 0x0098	4	Sets the rotor lag limit in motor steps	0 – 2147483647	102400	LG
<b>Position lead/lag</b>	0x0099 – 0x009A	4	Represent the number of counts that the rotor leads or lags the stator.  A positive value indicates position lag. A negative value indicates position lead	-2147483647 to +2147483647	—	LL
<b>Locked rotor</b>	0x009B	1	Indicates the state of the rotor as locked (1) or unlocked (0).	0/1	0	LR
<b>Locked rotor timeout</b>	0x009C – 0x009D	2	Sets the time in milliseconds in which the output bridge will disable after a locked rotor condition is detected.	2 – 65535	2000	LT
<b>Make up frequency</b>	0x009E – 0x009F	4	Sets the frequency in Hz at which missed steps are re-inserted into the move profile if make up mode = 1.	306 – 5000000	768000	MF
<b>Make up</b>	0x00A0	1	Sets the mode for make up steps. 0 = Off 1 = Make up steps at make up freq. (0x009E) 2 = Make up steps at system speed	0 – 2	0	MU
<b>Start configuration test</b>	0x00A1	1	Start configuration test process	—	—	SC
<b>Reserved</b>	0x00A2 – 0x00A4	—	Reserved	—	—	—
<b>Trip on hMT status</b>	0x00A3 – 0x00A4	4	Will execute an MCode subroutine on a preset hMTechnology status	—	0	TA
<b>Torque direction</b>	0x00A5	1	Sets the torque direction plus (1 – CW) or minus (0 – CCW) as seen facing the motor shaft.	0 – 1	1	TD
<b>Set torque</b>	0x00A6	1	Sets the motor torque in percent for torque mode operation.	1 – 100	25	TQ
<b>Set torque speed</b>	0x00A7		Determines the system speed for torque mode (AS=3) The device will perform the following calculation based upon the value of TS:  Oscillator frequency = 10 MHz / (TS+2)	0 – 255	0	TS

## 5.2 User variable registers

The user variable registers are ONLY used to interact with MCode programs being executed using the Manufacturer Specific function code. They cannot be used for MODBUS/TCP standalone operation.

If using V1 – V8 to store or retrieve data, the variables must be declared within the MCode program using the VA (Create user variable) command.

Function	Address	Bytes	Description	Range	Default	MCode
V1	0x00A8 - 0x00A9	4	User variable 1	Variables may contain up to 11 digits including the sign and may be used to store and retrieve data.	—	V1
V2	0x00AA - 0x00AB	4	User variable 2		—	V2
V3	0x00AC - 0x00AD	4	User variable 3		—	V3
V4	0x00AE - 0x00AF	4	User variable 4		—	V4
V5	0x00B0 - 0x00B1	4	User variable 5		—	V5
V6	0x00B2 - 0x00B3	4	User variable 6		—	V6
v7	0x00B4 - 0x00B5	4	User variable 7		—	v7
V8	0x00B6 - 0x00B7	4	User variable 8		—	V8

---

Page intentionally left blank



---

## 6 TCP/IP Configuration Utility

The TCP/IP configuration Utility is used to configure and rest the functionality of Lexium MDrive Ethernet units.

For installation and usage instructions see the Lexium MDrive Software Suite Manual available online at:

<http://motion.schneider-electric.com>

---

Page intentionally left blank

## **WARRANTY**

Reference the web site at [www.motion.schneider-electric.com](http://www.motion.schneider-electric.com) for the latest warranty and product information.

**Schneider Electric Motion USA**

370 North Main Street, P.O. Box 457

Marlborough, CT 06447 - U.S.A.

Tel. +00 (1) 860 295-6102 - Fax +00 (1) 860 295-6107

e-mail: [info@imshome.com](mailto:info@imshome.com)

<http://motion.schneider-electric.com>

© Schneider Electric Motion USA All Rights Reserved.

V1.00, 06.2013

*Product Disclaimer and most recent product information at*  
[www.motion.schneider-electric.com](http://www.motion.schneider-electric.com)

